INSTALLATION DIAGRAM - 6200/8200VS